
SiC series power quality
products
APF/SVG/ASVG

User Manual

Data version	A00
Archive date	13-05-2025
ERP encoded	19090021

Our company provides customers with a full range of technical support, users can contact the nearest company office or customer service center, or directly contact the company headquarters.

All rights reserved. Content is subject to change without notice.

Special statement

- Personal Safety

1. The installation of this product must be carried out by the professional engineer of the manufacturer or the manufacturer's authorized agent, and the debugging must be carried out by the engineer designated by the manufacturer, otherwise it may lead to product failure or endanger personal safety.
2. Before installing and debugging this product, be sure to read this product manual and safety matters in detail, otherwise it may lead to product failure or endanger personal safety.
3. This product should not be used as a power supply for any life support equipment.

- Equipment Safety

1. If stored or left unused for a long time, this product must be placed in a dry, clean and specified temperature range.
2. When the distortion rate of grid voltage is higher than 15%, the user needs to put forward special instructions in order to propose different solutions.
3. This product should be used in an appropriate working environment (see the environmental requirements section of this product manual for details).

It is forbidden to use this product in the following work environments:

- High temperature, low temperature or humid places that exceed the technical specifications of this product'.
- Places where there is vibration and are susceptible to collision.
- Close to heat sources or places with strong electromagnetic field interference.
- Places with corrosive gases and dusts.

Statement of Responsibility

Our company is not responsible for defects or malfunctions caused by the following reasons:

- Exceed the scope of use and working environment specified in the product
- Unauthorized modification or maintenance, wrong installation, improper operation
- Force majeure
- Other matters that violate the provisions of this product manual

This manual covers the following products

	product	
APF High Protection Active Filter - rail mount type	APF 100A	208/400/480Vac Three-phase four-wire/three-phase three-wire 100A modular APF - High Protection -Rail mount
	APF 150A	208/400/480Vac Three-phase four-wire/three-phase three-wire 150A modular APF - High Protection -Rail mount
APF High Protection Active Filter - wall mount type	APF 100A	208/400/480Vac Three-phase four-wire/three-phase three-wire 100A modular APF - High Protection -Wall mount
	APF 150A	208/400/480Vac Three-phase four-wire/three-phase three-wire 150A modular APF - High Protection -Wall mount
SVG High Protection static var generator - rail mount type	SVG 75KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 75KVar(400Vac) modular SVG -High Protection - Rail mount
	SVG 100KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 100KVar(400Vac) modular SVG -High Protection - Rail mount
SVG High Protection static var generator - wall mount type	SVG 75KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 75KVar(400Vac) modular SVG -High Protection - Wall mount
	SVG 100KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 100KVar(400Vac) modular SVG -High Protection - Wall mount
ASVG High Protection static var generator - rail mount type	ASVG 75KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 75KVar(400Vac) modular ASVG -High Protection - Rail mount
	ASVG 100KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 100KVar(400Vac) modular ASVG -High Protection - Rail mount
ASVG High Protection static var generator - wall mount type	ASVG 75KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 75KVar(400Vac) modular ASVG -High Protection - Wall mount
	ASVG 100KVar	208/400/480Vac Three-phase four-wire/three-phase three-wire 100KVar(400Vac) modular ASVG -High Protection - Wall mount

Table of Contents

I Overview	1
1.1 Security	1
1.2 Precautions for Use	2
1.3 Disposal Precautions	2
II Mechanical Installation	3
2.1 Precautions	3
2.2 Environmental Characteristics.....	3
2.3 Mechanical Characteristics.....	4
2.4 Electrical Characteristics.....	5
2.5 Installation Drawing	6
2.5.1 Operating Space	6
2.5.2 Structural Dimensions	6
2.5.3 Mechanical Installation	8
III Electrical Installation	9
3.1 Power Cable Routing.....	9
3.1.1 Input Current and Cable Recommendation	9
3.1.2 Power Cable Connection	10
3.2 Port Information	10
3.2.1 Front Panel Ports	10
3.2.2 Rear Panel Signal Ports	12
3.3 Signal Wiring Method	13
3.3.1 Wiring Method Between Module and Monitoring Screen	13
3.3.2 Wiring Methods for External Indicator Lights, Power On, Power Off, and Emergency Stop Buttons.....	14
3.3.3 4G Module (Optional Accessory)	16
3.4 CT Wiring Methods	17
3.4.1 Module Standalone Distribution (CT-Load Side)	17
3.4.2 Module Standalone Distribution (CT-Grid Side)	18
3.4.3 Multi-Module Parallel Distribution (CT-Load Side).....	18
3.4.4 Multi-Module Parallel Distribution (CT-Grid Side).....	19
3.4.5 Phase Sequence Adaptation and CT Direction.....	19
IV Power-On Operation Instructions	21
4.1 Module Power-On and Power-Off	21
4.1.1 Power-On Procedure	21
4.1.2 Power-Off Procedure.....	21
4.2 4.3-Inch LCD Display and Settings.....	22
4.3 7-Inch LCD Display and Settings.....	24
V Routine Maintenance and Care.....	28
5.1 Safety Precautions	28
5.2 Routine Inspections	28
5.3 Alarm List	29

Appendix I Product Module Warranty Form..... 31

Appendix II Notice to Users..... 32

I Overview

1.1 Security

This manual uses the following safety signs, so be sure to follow them!



Improper use can cause dangerous situations and is highly likely to lead to personal injury or death!



1. It is strictly forbidden to place flammable materials near this product module, as it poses a fire hazard.
2. It is strictly forbidden to install this product module in an environment containing explosive gases, as it poses a risk of explosion.
3. This product must be wired by a qualified professional to avoid the risk of electric shock.
4. Ensure the input power is completely disconnected before wiring work is carried out, otherwise there is a risk of electric shock. After power is applied, do not touch parts of the product module other than the operation panel.
5. The grounding terminal of this product module must be reliably grounded, as poor grounding can lead to abnormal operation and poses an electric shock hazard.
6. Maintenance operations should be carried out 15 minutes after disconnecting the power to this product, to avoid the risk of electric shock.
7. The exposed parts of the cable lugs in the main circuit wiring must be wrapped with insulating tape to avoid safety hazards.



1. When handling, do not lift the module of this product by the front panel handle to avoid personal injury or damage to the item.
2. Do not let screws, washers, or metallic foreign objects fall into the module of this product, as this poses a risk of fire and damage to the components.
3. If the module of this product is damaged or components are missing, do not install or operate it, as this poses a risk of fire and personal injury.
4. The main circuit terminals and wire lugs must be securely connected.

1.2 Precautions for Use

Incorrect Installation

If the module of this product is incorrectly installed or applied (such as the current transformer being connected in reverse), it can increase the harmonic current and reactive current in the power system, potentially endangering the power system or other equipment.

Exceeding Input Voltage Value

Please use the module within its rated voltage range. For special circumstances, use a step-up or step-down device.

Lightning Surge Protection

The module of this product is equipped with an overcurrent protection device for lightning strikes. After wiring correctly according to the manual, it has a certain level of self-protection against induced lightning.

1.3 Disposal Precautions

When disposing of this product module, please note:

- 1.The electrolytic capacitors on the printed circuit board may explode when incinerated.
- 2.Burning plastic components will produce toxic gases.
- 3.Please treat it as industrial waste for disposal.

II Mechanical Installation

2.1 Precautions

  Warning: Professional installation required	
1. Power can be applied to this product module only after obtaining the approval of the commissioning engineer. 2. The installation of this product module must be carried out by qualified engineers according to this user manual.	
 Note: Three-phase five-wire input power is required (the three-phase three-wire system does not connect the N line to this product module).	
This product module must be connected to a three-phase five-wire (A, B, C, N, PE) TN AC power distribution system (IEC60364-3). The three-phase three-wire system does not connect the N line to this product module.	
  Warning	
1. In order to ensure personal safety, the installation tools operated with electricity must be insulated with insulating gloves. 	

2.2 Environmental Characteristics

The power quality product module is a power electronic module equipped with complex control devices. **The installation environment may affect its operational reliability and service life.** This product module is equipped with a cooling fan to dissipate heat generated during operation. Therefore, do not block the ventilation openings during installation. Do not install this product module in environments that are excessively dusty, hot, humid, corrosive, or subject to vibration.

Table 2-1 Environmental characteristics

characteristics	Unit	Rated capacity of 400V	
		100A	150A
		75kvar	100kvar
Noise within 1m (front)	dB	<60dB	
altitude	m	≤1500, 1% derating per 100m in the range of 1500m~3000m	
relative humidity	%RH	0~95, No condensation	

Operating temperature	°C	-10~55°C When the ambient temperature is between -10 to 40°C, the system has no output power derating; when the ambient temperature is between 40 to 45°C, the system's output power is derated to 90%; when the ambient temperature is between 45 to 50°C, the system's output is derated to 80%; when the ambient temperature exceeds 55°C, a "High Ambient Temperature" fault occurs, and the functionality will be restored when the ambient temperature drops to 50°C.
Storage and transport temperature	°C	-20~+70
Overvoltage rating		Overvoltage Level II.

(* 1. This model is only suitable for SVG and ASVG; * 2. This model is only suitable for APF; * 3. This model is only suitable for SVG and ASVG)

2.3 Mechanical Characteristics

Table 2-2 Mechanical characteristics

Mechanical characteristics	Unit	Rated capacity of 400V	
		100A	150A
		75kvar	100kvar
Mechanical dimensions(W×D×H)	mm	500×520×100 (Rail mount type, No packaging material) ; 500×520×100 (Wall mount type, No packaging material) ; 657×167×164 (Rail mount type、Wall mount type, With packaging materials) ;	
Weight (maximum)	kg	22	26
Color	N/A	Black fine grain (customizable)	
Degree of protection, IEC (60529)	N/A	IP20(Front door opens or closes, back door closes)	

(* 1. This model is only suitable for SVG and ASVG; * 2. This model is only suitable for APF; * 3. This model is only suitable for SVG and ASVG)

2.4 Electrical Characteristics

Table 2-3 Electrical Characteristics of APF Product Module

Electrical characteristics	Unit	Rated capacity of 400V	
		100A	150A
Rated AC voltage	Vac	380/400/415, Three-phase four-wire/three-phase three-wire	
Current rating	A	100	150
Rated neutral current	A	3*100	3*150
frequency	Hz	50/60	
Frequency range	%	±10	
Voltage range	%Vac	Lower limit: -20; Upper limit: +15	
loss	%	<1	
CT ratio range		50:5~10000:5	

Table 2-4 Electrical Characteristics of SVG Product Module

Electrical characteristics	Unit	Rated capacity of 400V	
		75kvar	100kvar
Rated AC voltage	Vac	380/400/415, Three-phase four-wire/three-phase three-wire	
Current rating	A	100	150
Rated neutral current	A	100	150
frequency	Hz	50/60	
Frequency range	%	±10	
Voltage range	%Vac	Lower limit: -20; Upper limit: +15	
loss	%	<1	
CT ratio range		50:5~10000:5	

Table 2-5 Electrical Characteristics of ASVG Product Module

Electrical characteristics	Unit	Rated capacity of 400V	
		75kvar	100kvar
Rated AC voltage	Vac	380/400/415, Three-phase four-wire/three-phase three-wire	
Current rating	A	100	150
Rated neutral current	A	100	150
frequency	Hz	50/60	
Frequency range	%	±10	
Voltage range	%Vac	Lower limit: -20; Upper limit: +15	
loss	%	<1	
CT ratio range		50:5~10000:5	

2.5 Installation Drawing

2.5.1 Operating Space

Sufficient space should be reserved before and after installing the cabinet, so that people can freely pass through after the front and rear doors of the cabinet are fully opened. At the same time, at least 500mm of space should be reserved at the rear of this product to ensure proper heat dissipation and ventilation. After removing all dust films from the module, subsequent operations can be carried out.

2.5.2 Structural Dimensions

Figures 2.1 to 2.2 illustrate the structural dimension diagrams of various types of high-protection-grade power quality product modules.




Figure 2.1 APF 100A~150A / SVG、ASVG 75kvar~100kvar -Rail Mounted




Figure 2.2 APF 100A~150A / SVG、ASVG 75kvar~100kvar – Wall Mounted

2.5.3 Mechanical Installation

When installing the universal rail-mounted module, it is fixed to the installation pillars of the cabinet through the front two side ears, as shown in Figure 2.5. Wall-mounted models should be secured to a solid wall along the upper and lower edges or hung within the cabinet




Figure 2.5 Schematic diagram of the rail-mounted model

III Electrical Installation

3.1 Power Cable Routing

3.1.1 Input Current and Cable Recommendation

The user installation power cables must comply with the reference values provided in Tables 3.1 to 3.3.

Table 3-1 Recommended rated capacity and cross-sectional area of copper core cables for APF products
(‘3*’ means 3 cores)

Type	Rated Capacity			
	50A	75A	100A	150A
Recommended phase cable(mm ²)	16	25	35	50
Recommended neutral cable(mm ²)*	3*16	3*25	3*35	3*50
Recommended PE wire and cable(mm ²)	16	16	16	25
Power terminal screw	M6	M6	M6	M8
Suggested tightening torque(N•m)	10	10	10	25

Table 3-2 Recommended rated capacity and cross-sectional area of copper core cables for SVG products

Type	Rated Capacity			
	35kvar	50kvar	75kvar	100kvar
Recommended phase cable(mm ²)	16	25	35	50
Recommended neutral cable(mm ²)*	16	25	35	50
Recommended PE wire and cable(mm ²)	16	16	16	25
Power terminal screw	M6	M6	M6	M8
Suggested tightening torque(N•m)	10	10	10	25

Table 3-3 Recommended rated capacity and cross-sectional area of copper core cables for ASVG products

Type	Rated Capacity			
	35kvar	50kvar	75kvar	100kvar
Recommended phase cable(mm ²)	16	25	35	50
Recommended neutral cable(mm ²)*	16	25	35	50
Recommended PE wire and cable(mm ²)	16	16	16	25
Power terminal screw	M6	M6	M6	M8
Suggested tightening torque(N•m)	10	10	10	25



NOTE

To ensure the safe operation of the equipment, the ground connection must use the shortest possible routing path.

3.1.2 Power Cable Connection




Figure 3-1 Terminal block (rear view)

1. Connect the input ground wire to the input grounding terminal. Note: The ground connection must comply with local and national regulations.
2. When routing the AC input cable, avoid passing it near the module's air outlet, ensuring that there are no obstructions within 20 cm of the module's air outlet.
3. When installing the power cables for a three-phase three-wire system, do not connect the N wire.
4. The ground connection must use the shortest possible routing path.

Table 3-4 APF power terminal definitions

Terminal symbol	Description of the terminal function
A	A-phase input and output terminal
B	B-phase input and output terminal
C	C-phase input and output terminal
N	Three-phase four-wire center line
PE	Safety Ground Terminal (Enclosure)

3.2 Port Information

3.2.1 Front Panel Ports

Figure 3.2 shows the signal ports on the front panel of the high-protection model. Users who need to perform parallel compensation with multiple modules must assign a unique ID number to each module

by rotating the rotary switch marked "ID." **It is not allowed for multiple modules performing parallel compensation to use the same ID number, as this will prevent communication.**

Note: If the rotary switch displays "0" ,the corresponding ID number for that module is "1" .




Figure 3.2 Front Panel Signal Ports

The status of the indicator lights and their meanings are shown in Table 3.5.

Table 3.5 Status of Indicator Lights and Their Meanings

Indicator Light	Color	Mode	Meaning
ALM	Red	On	Module fault exists
RUN	Green	Flashing	Powering on
		Steady	Running
POW	Yellow	On	Powered on

The network port marked with the "Debug\PC/HMI" silkscreen is for debugging purposes by our staff and is not open to users.

3.2.2 Rear Panel Signal Ports

The definitions of the signal ports are shown in Figure 3.3, and the descriptions of each signal can be found in Table 3.3. It is strictly prohibited to apply external power when wiring the rear panel ports!




Figure 3.3 Rear Panel Signal Ports for High Protection Models

Table 3.6 Functions and Wiring Instructions for Rear Panel Signal Ports of High Protection Models

Property	Terminal Function	Port Name	Wiring Instructions
Output	Fault Indicator	+24V	Connect to the anode of the external LED
		LED_F	Connect to the cathode of the external LED
	Running Indicator	+24V	Connect to the anode of the external LED
		LED_R	Connect to the cathode of the external LED
Input	Emergency Stop	EPO	Emergency shutdown dry contact
		GND	Grounding terminal
	Manual Start	ON	Power on signal input dry contact
		GND	Grounding terminal
	Manual Stop	OFF	Shutdown signal input dry contact
		GND	ON
Output	Module Control Capacitor	485_1-	When compensating for multiple modules, only the module with ID 1 can control the capacitor, corresponding to a rotary dial setting of 0
		485_1+	
Output	Load CT Sampling S2 Output		Empty Interface, Anti-misconnection
		IA_S2	Connect to the S2 terminal of phase A CT
		IB_S2	Connect to the S2 terminal of phase B CT

Input		IC_S2	Connect to the S2 terminal of phase C CT
	Load CT Sampling S1 Output	IA_S1	Connect to the S1 terminal of phase A CT
		IB_S1	Connect to the S1 terminal of phase B CT
		IC_S1	Connect to the S1 terminal of phase C CT
	485_2 (Large Screen Communication) Matching Resistor	485_2-120Ω	Switch to "ON" to activate, see Section 3.3.1
Communication	CAN (Module Grid Side Parallel) Matching Resistor	CAN-120Ω	Switch to "ON" to activate, see Section 3.3.1
	Large Screen Communication and Module Source Side Wiring Port	COM	See Section 3.3.1
		COM	
	4G Module	4G Module	Select accessories and support users to obtain module data through the APP. Please refer to section 3.3.3 for download methods

3.3 Signal Wiring Method

3.3.1 Wiring Method Between Module and Monitoring Screen

If the monitoring screen is only connected to one module, refer to Figure 3.4 .

Wiring Method for the Monitoring Screen: Insert one end of the pre-fabricated cable's DB9 connector into the DB9 interface of the monitoring screen and secure it with the locking screws. The other end, marked with "24V," should be connected to the 2PIN Phoenix terminal interface on the monitoring screen.

Wiring Method for the Module: Insert the crystal head of the pre-fabricated cable into one of the COM ports on the back panel of the module. The two COM ports marked with "COM" on the same module are identical, and there is no need to differentiate between them during wiring.




Figure 3.4 Communication Wiring Diagram Between the Monitoring Screen and Module

Multi module parallel operation requires the connection between the module and the large screen through a communication line. The communication line is in the delivery accessories. The user only needs to insert the crystal head into the COM port of the module in the way shown in Figure 3.5. After the communication line is connected, turn the 485_2matching resistance of the first and last modules to "on" to improve the reliability of 485_2communication.

If the multi module parallel CT is connected to the power grid side, after the communication line is connected, turn the can_matching resistance of the first and last modules to "on" to improve the reliability of CAN communication.




Figure 3.5 Schematic Diagram of 485_2 and CAN Communication Wiring

Before using different power quality product modules for parallel compensation, please refer to Table 3.7 to confirm whether the modules can operate in parallel. If incompatible product modules are used in parallel, they will not function properly.

Table 3.7 Compatibility of Power Quality Products for Parallel Operation

	APF	SVG	ASVG
APF	✓	✓	×
SVG	✓	✓	×
ASVG	×	×	✓

3.3.2 Wiring Methods for External Indicator Lights, Power On, Power Off, and Emergency Stop Buttons

Each module provides a set of wiring terminals for operation and fault indicator lights. The voltage level for the indicator lights should be 24VDC. The schematic diagrams for the wiring principles are shown in Figures 3.6 and 3.7. For detailed wiring terminals, refer to Table 3.6 .




Figure 3.6: Wiring Diagram for Operation Indicator Lights




Figure 3.7: Wiring Diagram for Fault Indicator Lights

Each module is provided with a set of manual power on wiring ports. When multiple modules are paralleled, the power on dry nodes of all modules can be cascaded. The schematic diagram of the recommended wiring principle is shown in Figure 3.8. When the manual power on mechanical switch is effective, all modules cascaded at the button port will be powered on at the same time.




Figure 3.8: Wiring Diagram for Manual Power-On Mechanical Switch in Parallel Modules

Each module is provided with a set of manual shutdown connection ports. When multiple modules are paralleled, the shutdown dry nodes of all modules can be cascaded. The schematic diagram of recommended wiring principle is shown in Figure 3.9. When the manual shutdown mechanical switch takes effect, all modules cascaded at the button port will be shut down at the same time.




Figure 3.9: Wiring Diagram for Manual Power-Off Mechanical Switch in Parallel Modules

Each module is provided with a set of emergency stop wiring ports. When multiple modules are paralleled, the emergency shutdown of all modules can be cascaded. The schematic diagram of the

recommended wiring principle is shown in Figure 3.10. When the emergency stop mechanical switch is effective, all modules cascaded at the button port will be emergency stopped at the same time.

Note: the emergency stop mechanical switch must be reset before the module can be started again. Otherwise, the module cannot be powered on..




Figure 3.10: Wiring Diagram for Emergency Stop Mechanical Switch in Parallel Modules

3.3.3 4G Module (Optional Accessory)

The 4G module is an optional part, and its appearance is shown in Figure 3.11. After installing the 4G module, the user can obtain the data information of the module through the app.

After the module is equipped with 4G module, you can view the data information of the module through the mobile app.




Figure 3.11: Appearance of the 4G Module

In order to ensure that the 4G module can work reliably, the following checks should be done during assembly:

1. maintain reliable connection between 4G module and equipment interface;
2. the power indicator of 4G module is on.

The download QR code of app is shown in Figure 3.12. Open wechat and scan the QR code below to get help in using the software.



Figure 3.12: Data Management App for the 4G Module

3.4 CT Wiring Methods

Figure 3.13~figure 3.16 show the CT wiring diagram of our power quality product module. It is recommended that the user install CT on the load side as far as possible, and the wiring mode is shown in Figure 3.13. If the CT is connected to the grid side, refer to figure 3.14.

CT is a directional device, and the wrong wiring will lead to a series of problems such as the reverse compensation. Refer to Fig. 3.13 to Fig. 3.16 for the orientation of CT body and the direction of CT outgoing line. P1/p2 in the figure represents the orientation of CT, and s1/s2 represents the direction of CT outgoing line.

The connection of power line and CT line in the following part of the figure takes phase a as an example. The solid line is the power line, the wide dotted line is the CT line, and the thin dotted line is the signal line. Refer to section 3.3.1 for the wiring method of 485_2 and can communication line.

3.4.1 Module Standalone Distribution (CT-Load Side)




Figure 3.13: Module Standalone Power Distribution with CT on the Load Side

3.4.2 Module Standalone Distribution (CT-Grid Side)




Figure 3.14: Wiring Diagram for Module Standalone Power Distribution with CT on the Grid Side

3.4.3 Multi-Module Parallel Distribution (CT-Load Side)

In parallel power distribution, to determine the compensation amount for each module, all modules must be connected to the large screen via the 485_2 communication line. Details can be referenced in Section 3.3.1.




Figure 3.15: Wiring Diagram for Multi-Module Parallel Operation with CT on the Load Side

3.4.4 Multi-Module Parallel Distribution (CT-Grid Side)

In addition to the instructions in Section 3.4.3, when CTs are connected on the grid side in parallel power distribution, both 485_2 and CAN communication lines must be connected. This is shown in Figure 3.16 and details can be referenced in Section 3.3.1.




Figure 3.16: Wiring Diagram for Multi-Module Parallel Operation with CT on the Grid Side

3.4.5 Phase Sequence Adaptation and CT Direction

In some applications, users may be unable to confirm the correct phase sequence of the three-phase power lines. In such cases, the module's "Phase Sequence Adaptation" function can be enabled. The principle diagram is shown in Figure 3.17. To activate the "Phase Sequence Adaptation" function, users can access the monitoring screen parameter settings interface shown in Figure 4.2, select "Enable" for the "Phase Sequence Adaptation" option, and click "Confirm Settings" to activate it.




Figure 3.17: Schematic Diagram of CT Phase Sequence Adaptation Wiring

Once "Phase Sequence Adaptation" is enabled, the module can function correctly even if the exact phases are unknown, as long as the power lines and CT lines correspond to the same phase on the module.

Except for photovoltaic (PV) applications, the equipment will also check whether the S1/S2 direction of all three phases are reversed. By enabling the setting, "CT Direction" can realize all three phases CT are simultaneously reversed.

IV Power-On Operation Instructions

4.1 Module Power-On and Power-Off

4.1.1 Power-On Procedure

This power-on procedure applies to powering on the module when it is completely powered off. Follow the steps below:

1. Secure the module casing and connect power and signal cables.

Warning: During the power-on process, the module's output terminals may already be live. If there are loads connected to the module's output terminals, ensure it is safe to supply power to the load. If the load is not ready to receive power, ensure the load is safely isolated from the module's output terminals.

2. Close the isolation switch between the grid and the module.

At this point, the LCD display screen will start up. The front panel **indicator lights** will show as follows:

Fault (red)

Operation (green)

Power-On (yellow)

Indicator light behavior:

Power-on process: Green light blinks rapidly.

Normal operation: Green light remains steady on.

Fault state: Red light is illuminated, and the module cannot power on.

Yellow light on: Indicates the module is in a power-on state.

4.1.2 Power-Off Procedure

There are two methods to power off the module:

1. Completely Power Off by Disconnecting the Isolation Switch

This is a full power-off mode where the internal energy of the module is discharged slowly after the isolation switch is turned off.

Warning: the yellow light is off at this time, which does not mean that the module is not charged. The module can be overhauled only after it has been left for 15 minutes. Non professionals are strictly prohibited to perform this operation.

2. Standby Power-Off via the LCD Control Panel or External Button

This method only shuts down the power components in the system, leaving the module in standby mode.

4.2 4.3-Inch LCD Display and Settings

When powered on, the LCD screen will light up and enter the "Parameter Settings" interface. Enter the password "123456", as shown in Figure 4.1.




Figure 4.1: Parameter Settings - Password Input

The parameter settings interface consists of two pages. The first page of parameter settings is the same for APF, SVG, and ASVG modules. The settings mainly include—Starting Mode, Target COS Φ , CT Location, CT Ratio, CT Direction, Phase Order Adapt, PV Mode (Solar Power Mode) and Wire System Selection. After selecting the desired parameter, click the "Confirm" button on the right hand side of the screen to apply the changes to take effect.




Figure 4.2 Parameter Setting First Page Common Interface

The second page of parameter settings mainly include—Function Selection, Compensating Harmony Number, Compensation Mode, Current Loop Ratio and Reactive Set. After selecting the desired

parameter, click the "Confirm" button on the right head side of the screen to apply the changes to take effect.

The second page of parameter setting for APF, SVG and ASVG models is shown in Figure 4.3 to Figure 4.5.




Figure 4.3 Parameter Settings for APF Interface




Figure 4.4 Parameter Settings for SVG Interface




Figure 4.5 Parameter Settings for ASVG Interface

4.3 7-Inch LCD Display and Settings

When powered on, the 7-inch LCD screen will light up and enter the "Parameter Settings" interface. Enter the password "123456", as shown in Figure 4.6. For multiple modules connected in parallel distribution, parameters need to be set individually for each module, ensuring consistency across all modules.




Figure 4.6: Parameter Settings - Password Input

The parameter settings interface consists of two pages. The first page of parameter settings is the same for APF, SVG, and ASVG modules. The settings mainly include—Starting Mode, Target COS Φ , CT Location, CT Ratio, CT Direction, Phase Order Adapt, PV Mode (Solar Power Mode) and Wire System Selection. After selecting the desired parameter, click the "Confirm" button on the right hand side of the screen to apply the changes.




Figure 4.7: Common Parameter Settings Interface

The second page of parameter settings mainly include—Function Selection, Compensating Harmony Number, Compensation Mode, Current Loop Ratio and Reactive Set. After selecting the desired parameter, click the "Confirm" button on the right hand side of the screen to apply the changes to take effect. **(Note: In most cases, settings on this page are not required.)**

The second page of parameter setting for APF, SVG and ASVG models is shown in Figure 4.8 to Figure 4.10.

Standby APF 12A 012V 12HZ 0012 - 12 - 12 12 : 12 : 12

Function: Harmonic Reactive Unbalance Set

Number: ☐ 3th ☐ 5th ☐ 7th ☐ 9th ☐ 11th ☐ 13th ☐ 2th
☐ 15th ☐ 17th ☐ 19th ☐ 21th ☐ 23th ☐ 25th ☐ 4th
☐ 27th ☐ 29th ☐ 31th ☐ 33th ☐ 35th ☐ 37th ☐ 6th
☐ 39th ☐ 41th ☐ 43th ☐ 45th ☐ 47th ☐ ≥49th ☐ 8th

Compen Mode: Combo Box

Current Loop Coefficient: 1234

Reactive Set: 12%

HomePage Parameter Capacitance Setting Record Module

Figure 4.8: Parameter Settings for APF Interface

Standby SVG 12Kvar 012V 12HZ 0012 - 12 - 12 12 : 12 : 12

Function: Reactive Set

Current Loop Coefficient: 1234

Reactive Set: 12%

HomePage Parameter Capacitance Setting Record Module

Figure 4.9: Parameter Settings for SVG Interface

Standby ASVG 12Kvar 012V 12HZ 0012 - 12 - 12 12 : 12 : 12

Function:

Number: ☐ 3th ☐ 5th ☐ 7th ☐ 9th ☐ 11th ☐ 13th

Compen Mode:

Current Loop Coefficient:

Reactive Set:

HomePage Parameter Capacitance **Setting** Record Module

Figure 4.10: Parameter Settings for ASVG Interface

The 7-inch screen supports up to 16 modules in parallel distribution. The "Home" and "System Parameters" interfaces display system-level parameters, while the "Capacitor Information" interface shows details of the controlled capacitors. The "Module Information" interface provides specific information for each module, as shown in Figure 4.11.

Standby APF 12A 012V 12HZ 0012 - 12 - 12 12 : 12 : 12

Machine Type: SVG
Module Capacity: 12A
DSP Version: V 0012 B 012 D 012
FPGA Version: V 0012 B 012 D 012

	S(KVA)	Load(%)	I(A)	INV(V)	BUS(V)	IGBT(°C)	AMBI(°C)	N Line(A)
A	12.3	12.3	12.3	12.3	12.3			
B	12.3	12.3	12.3	12.3		12.3	12.3	12.3
C	12.3	12.3	12.3	12.3	12.3			

Module Compensation Information

HomePage Parameter Capacitance Setting **Module** Record

Figure 4.11: Module Parameter Information

V Routine Maintenance and Care

5.1 Safety Precautions

Modules operate with high voltage. For safety, maintenance personnel must not touch any live terminals while the equipment is in operation. Ensure the grounding terminal of the equipment is reliably connected.

Due to the large number of capacitors in the module's bus, maintenance and inspection should only be performed 15 minutes after power is disconnected.

5.2 Routine Inspections

Do not open the module during operation or while it is powered. Perform a visual inspection from the outside to check for any abnormalities in the operation. The following items should typically be inspected:

1. Whether the display screen data meets requirements.
2. Whether the display screen shows any fault information.
3. Any abnormal sounds, vibrations, or odors.
4. Signs of overheating, discoloration, or other irregularities.
5. When following safety precautions, periodic inspections should be conducted after disconnecting the module from the grid.

The routine inspection items are listed in Table 5.1.

Table 5.1: Routine Inspection Items

category	Check the items	remark
circumstances	Temperature, humidity, presence of metal dust, corrosive gases	
Electrical connections	Whether the cables and terminals are damaged	
	Whether the main circuit wiring, grounding wire, CT wiring, communication wiring, etc. are reliably connected	
Heat dissipation of the device	Whether there is a blockage in the air duct	

5.3 Alarm List

This table outlines the comprehensive alarm information that can be accessed through the "Current Records" and "Historical Records" menus on the module's display interface. Each entry includes the alarm type, and description for troubleshooting.

Table 5.2 Alarm List

Alarm	interpretation
Reset	Fault reset
Manual startup	Manually turn on the module on the touch screen
Manual shutdown	Manually turn off the module on the touch screen
Soft Start Failure	Abnormalities in bus voltage or inverter output voltage during the soft-start process.
Abnormal Grid Voltage	Grid voltage exceeds 115% of the rated voltage or drops below 85% of the rated voltage.
Abnormal Grid Frequency	Grid frequency exceeds 3Hz above or drops 3Hz below the rated frequency.
Abnormal Grid Phase Sequence	Grid phase sequence is ACB, BAC, or CBA.
Input Neutral Missing	Main circuit input neutral line (N) not detected.
Bus Undervoltage	Bus voltage drops below 80% of the rated voltage.
Bus Overvoltage	Bus voltage exceeds 120% of the rated voltage.
Relay or Fuse Open Circuit	At least one output fuse or relay is in an open-circuit state.
Relay Short Circuit	At least one relay is closed without an enable signal.
Overload Timeout	Current overload during or after the soft-start process.
Auxiliary Power Abnormal	Auxiliary power failure or power loss.
Emergency Shutdown	Emergency stop (EPO) switch on the touch control panel is pressed, or external EPO command is received.
Fan Abnormality	At least one fan has failed.
Abnormal Output Current	Actual output current differs from the IGBT bridge arm output current by more than 20% of the rated current.
Overtemperature (Environment)	Ambient temperature exceeds 55°C.
Overtemperature (IGBT)	IGBT temperature too high
CT Polarity Reversed	Secondary side of the current transformer (S1, S2) is reversed.

Alarm	interpretation
CT Current Overload	CT current exceeds 1.2 times the CT sampling range.
CAN Communication Failure	CAN cable not connected or loose when CT is positioned on the grid side.
Communication Failure	No 485 communication modules detected.
Model Mismatch	Alarm triggered if different models are used in a parallel configuration.
Voltage Level Mismatch	Alarm triggered if different modules have different voltage levels in a parallel configuration.
Frequency Level Mismatch	Alarm triggered if different modules have different frequency levels in a parallel configuration.
Start Method Mismatch	Alarm triggered if different modules use different start methods in a parallel configuration.
Target Cosine Value Mismatch	Alarm triggered if different modules have different target $\cos\phi$ values in a parallel configuration.
CT Position Mismatch	Alarm triggered if different modules have different CT positions in a parallel configuration.
CT Ratio Mismatch	Alarm triggered if different modules have different CT ratios in a parallel configuration.
Compensation Function Mismatch	Alarm triggered if different modules have different compensation functions in a parallel configuration.

Appendix I Product Module Warranty Form

User Units:	
Address:	
Zip:	Fax:
Contact:	Phone:
Machine No.:	
Contract No.:	Date of purchase:
Service Units:	
Contact:	Phone:
Users' evaluation of service quality: ☐ Good ☐ Better ☐ ordinary ☐ Bad Other comments: User signatures: Date:	
Customer service center return visit record: ☐ Telephone return visits ☐ Letter return visit Other: Signature of Technical Support Engineer: Date:	

Note: This order will be invalid if the user cannot be returned.

Appendix II Notice to Users

1. The scope of warranty refers to the APF device itself.
2. During the warranty period, if the product fails or is damaged, our company will repair it free of charge.
3. The starting time of the warranty period is the date of manufacture of our company, and the machine code is the only basis for judging the warranty period.
4. Even during the warranty period, a certain repair fee will be charged if the following occurs:
 - Machine failure caused by not operating according to the user manual;
 - Machine damage caused by fire, flood, abnormal voltage, etc.;
 - Damage caused when the device is used for non-normal functions.
5. The service fee is calculated according to the actual cost, if there is another contract, the principle of contract priority shall be used.
6. Please be sure to keep this card and present it to the repair unit during the warranty.